



## RECESSED MEDICINE CABINET

### BEFORE INSTALLATION

Please review Recessed Medicine Cabinet Installation Instructions. Observe all local building and safety codes. Handle mirrors and glass with care. Never place mirrored door directly on tiled floor (you will chip the corners).

### INSTRUCTIONS

Carefully unpack and inspect the product. If you find any damage, please contact your place of purchase. **DO NOT INSTALL THE ITEM.** Failure to follow this instruction may result in the forfeiture of your product warranty.

A recessed medicine cabinet needs to be secured inside the wall to rectangular framing. This framing must be clear of all obstructions. If there are any wires, pipes or plumbing that cannot be relocated, you will need to order a full mounting kit that includes the hardware and mirrors to surface mount a cabinet.

**Please review product specification sheet on item ordered for proper rough opening dimensions. These can be obtained through your place of purchase or via our website, [sofiamedicinecabinets.com](http://sofiamedicinecabinets.com).**

We recommend consulting a licensed professional if you are unfamiliar with this type of installation. Sofia Medicine Cabinets accepts no liability for damage to the product or wall, or for personal injury during installation.

Please note we do not supply hardware for installation of recessed medicine cabinets.

All products fully assembled and adjusted, ready for installation.

If you require further assistance or have questions installing your cabinet, contact Customer Service at 718-366-1966.

### RECOMMENDED TOOLS



Level



Drill



Tape Measure

### INSTALLATION

1. Within the cabinet on the side walls, you will find the below plastic square caps (FIG. 1). Remove these to expose the screw holes (FIG. 2) from within the inside track of your medicine cabinet. Take care not to lose these, you will need to re-install these once the cabinet is secured into the framing.



FIG. 1

2. Secure cabinet into framing by way of pre-drilled screw holes. For most applications, 1 5/8" drywall screws (not provided) will suffice. Do not overtighten (there is a risk of bowing out the cabinet). Repeat on both sides and replace the caps. Depending on the plumbness of the wall, you may have to readjust the door.



FIG. 2

3. Congratulations! You have successfully installed your new medicine cabinet and it is now ready for use. We thank you for your purchase of a Sofia Medicine Cabinet.



# Made In the U.S.A.