



## WIRING & INSTALLATION GUIDE FOR CALYPSO COLLECTION

*Thank you for your purchase of one of our products. All items manufactured with pride in the USA.*

Please note that your LED Backlit Wall Mirror has been delivered fully assembled, and wired ready for installation. When unpacking your mirror please take care not to place on tiled, or bare floor (you will chip the corners!). **DO NOT PLACE ITEM ON FACE OF GLASS AS YOU RISK SCRATCHING THE MIRROR.** The mirror includes protective measures for safe shipping. Remove any and all of these protectors once item is installed.

Prepare your space as per our product specification sheet for the item that you purchased. We recommend all electrical components to be wired by a licensed professional.



Located approximately 5" down from the top of your mirror, and approximately halfway across on the back side of the mirror, (within the housing) you will find your wire whip (approximately 7" supplied). Here you find a black wire, a white wire, and a green wire. These go to a 115v AC source coming from the bathroom switch, (connect black to black, white to white and green to ground).

**PLEASE NOTE: DO NOT WIRE THIS BACKLIT MIRROR TO A DIMMER SWITCH, YOU WILL BURN OUT THE LED LIGHTING.**



Our Calypso Mirror comes complete with Z-Bar (shown above) for wall mounting. With the use of a level, secure Z-Bar to wall with hardware provided. We recommend hitting at least one stud, or the use of molly wall anchors if you cannot.

For additional questions/inquiries, please contact our customer support hotline at 718-366-1966 or via email at [sofiacabinets@gmail.com](mailto:sofiacabinets@gmail.com). Live chat is available 24/7 on our website; [sofiamedicinecabinets.com](http://sofiamedicinecabinets.com).