

INSTALLATION INSTRUCTIONS FOR COMBINATION CABINETS WITH STATIONARY MIRROR

1. **CAUTION:** To avoid any damage to the mirrors, carefully unpack the cabinets on a clean surface, such as a bed or carpeted floor, **NEVER REST MIRRORS OR MIRRORED CABINETS ON BARE FLOOR.** Unpack and inspect all items beginning with the stationary mirror. Inspect carefully to assure that all boxes are intact and free of breaks in the corrugation. If any damage is discovered you must **STOP**, and if possible take photos of the damage and repack carefully, (**DO NOT REMOVE THE PROTECTIVE CORNERS**) you must contact the PLACE of purchase, and provide them with all appropriate details.
2. Once you are satisfied that everything is as it should be, you may begin with the installation process.
3. The first item to be installed should be the stationary mirror. Determine the height at bottom, generally **nine inches from the vanity or sink.** Take special precautions to allow for clearance of the faucet. Place a level at the determined height and draw a line the full length of the vanity (**we will call this line A**). Locate the center of your vanity and draw a vertical line to the height of the stationary mirror up to the exact height of the mirror you are installing, 30" 36" or 40" (**we will call this line B**) Measure 5 ¼ "down from the top of line (**B**), we will call this line (**C**) draw a level line approximately the width of the stationary mirror. This is where the hanger will be installed.
4. Unpack the stationary mirror hanger that is packed with the stationary mirror. You will notice there is a vertical line marking the center of the bracket, align it with the vertical line (**C**) holding firmly in place, mark the mounting holes and install nylon anchors and mount the bar firmly in place. You can now install the stationary mirror by carefully sliding it over the bracket. When finished your mirror should be at the desired height and perfectly levelled.
5. The next item to install will be the shelf bar. First, align the center of the bar (You will find the center marked). Place the bar directly under the mirror and center it. While firmly holding in position, mark the mounting holes. Insert screw anchors, and proceed with shelf installation. You are now ready to install the cabinets.
6. Beginning with the left cabinet, install the side-kit mirror to the right side of the left cabinet. Remove protective film from the tape strips and secure the side mirror in place. Place the "Z" bar on the same line (**A**) that the stationary mirror is on and mark the holes, (be sure to allow left to right adjustment. Place the cabinet above the (**Z bar**) and allow it to slide in place (at all times take care not to damage the mirror). While holding the cabinet in place (we recommend an additional person for this task) you may now secure the cabinet by sliding the top mounting clips in place (**BE SURE TO LOCATE A STUD FOR AT LEAST ONE OF THE CLIPS**) before you tighten the screws slide the cabinet until it meets the stationary mirror.
7. Check to see that the left cabinet and the stationary mirror are level and lined up with the vanity.
8. You are now ready to install the Right cabinet. Repeat steps (in paragraph 6) that were taken with the left cabinet.

