



RECEPTACLE OPTIONS, PLACEMENT & WIRING LOCATION GUIDE



Our receptacle options are customizable in that they are not in one standard location. Their placement differs depending on the model ordered and location specified. Below we outline your options and their possible placement.

OB-2	USBA-2	USBC-2	OBUSBA-2*	OBUSBC-2*
DUPLEX GFCI RECEPTACLE	4 PORT USB TYPE-A RECEPTACLE	2 PORT USB TYPE-A / 2 PORT USB TYPE-C RECEPTACLE	COMBINATION DUPLEX GFCI RECEPTACLE & 4 PORT USB TYPE-A RECEPTACLE	COMBINATION DUPLEX GFCI RECEPTACLE & 2 PORT USB TYPE-A / 2 PORT USB TYPE-C RECEPTACLE
WIDTH: 3 1/8" HEIGHT: 5 1/4" DEPTH: 2 3/4"	WIDTH: 3 1/8" HEIGHT: 5 1/4" DEPTH: 2 3/4"	WIDTH: 3 1/8" HEIGHT: 5 1/4" DEPTH: 2 3/4"	WIDTH: 10 1/8" HEIGHT: 5 1/4" DEPTH: 2 3/4"	WIDTH: 10 1/8" HEIGHT: 5 1/4" DEPTH: 2 3/4"

***INSTALLED AT THE TOP OF A MEDICINE CABINET. RECEPTACLE OPTION NOT COMPATIBLE WITH TRIPLE DOOR MEDICINE CABINETS 30" – 36" IN WIDTH.**



OB-2 / USBA-2 / USBC-2 ACCESSORY PLACEMENT:

SINGLE DOOR CABINETS (UP TO AND INCLUDING 40" HEIGHT): RECEPTACLE GETS INSTALLED IN OPPOSITE BOTTOM CORNER OF MEDICINE CABINET FROM DOOR HINGING. **MUST SPECIFY.**

SINGLE DOOR CABINETS (72" HEIGHT ONLY): RECEPTACLE GETS INSTALLED ON OPPOSITE SIDE WALL FROM DOOR HINGING. **MUST SPECIFY.**

DOUBLE DOOR CABINETS (UP TO AND INCLUDING 36" WIDTH): RECEPTACLE GETS INSTALLED ON EITHER LEFT OR RIGHT SIDE WALL OF MEDICINE CABINET. **MUST SPECIFY.**

DOUBLE DOOR CABINETS (INCLUDING AND ABOVE 39" WIDTH): RECEPTACLE GETS INSTALLED BEHIND LEFT OR RIGHT SIDE DOOR IN OPPOSITE BOTTOM CORNER FROM DOOR HINGING (CABINET OPENS LIKE A WARDROBE). **MUST SPECIFY.**

TRIPLE DOOR CABINETS (UP TO AND INCLUDING 36" WIDTH): RECEPTACLE GETS INSTALLED ON EITHER LEFT OR RIGHT SIDE WALL OF MEDICINE CABINET. **MUST SPECIFY.**

TRIPLE DOOR CABINETS (INCLUDING AND ABOVE 39" WIDTH): RECEPTACLE GETS INSTALLED BEHIND LEFT, MIDDLE OR RIGHT DOOR IN OPPOSITE BOTTOM CORNER FROM DOOR HINGING (STANDARD TRIPLE DOOR HINGING IS LEFT MOST DOOR HINGED RIGHT, MIDDLE DOOR HINGED LEFT AND RIGHT MOST DOOR HINGED LEFT). **MUST SPECIFY.**

OBUSBA-2 / OBUSBC-2 ACCESSORY PLACEMENT:

SINGLE DOOR CABINETS (UP TO AND INCLUDING 40" HEIGHT): RECEPTACLE GETS INSTALLED AT THE TOP OF MEDICINE CABINET.

SINGLE DOOR CABINETS (72" HEIGHT ONLY): RECEPTACLE GETS INSTALLED ON OPPOSITE SIDE WALL FROM DOOR HINGING.

DOUBLE DOOR CABINETS (UP TO AND INCLUDING 36" WIDTH): RECEPTACLE GETS INSTALLED ON EITHER LEFT OR RIGHT SIDE WALL OF MEDICINE CABINET. **MUST SPECIFY.**

DOUBLE DOOR CABINETS (INCLUDING AND ABOVE 39" WIDTH): RECEPTACLE GETS INSTALLED BEHIND LEFT OR RIGHT MOST DOOR AT TOP OF MEDICINE CABINET. **MUST SPECIFY.**

TRIPLE DOOR CABINETS (INCLUDING AND ABOVE 39" WIDTH): RECEPTACLE GETS INSTALLED BEHIND LEFT, MIDDLE OR RIGHT DOOR AT TOP OF MEDICINE CABINET. **MUST SPECIFY.**



OB-2 / USBA-2 / USBC-2 WIRING LOCATION:

SINGLE DOOR CABINETS (UP TO AND INCLUDING 40" HEIGHT): 7/8" HOLE (WITH GROMMET) LOCATED ON OPPOSITE SIDE WALL OF CABINET FROM DOOR HINGING. 3" UP FROM BOTTOM OF CABINET, 2" IN FROM BACK OF CABINET (FOR STANDARD DEPTH CABINET, 3" IN FROM BACK OF CABINET FOR DEEPER DEPTH CABINET).

SINGLE DOOR CABINETS (72" HEIGHT ONLY): 7/8" HOLE (WITH GROMMET) LOCATED ON OPPOSITE SIDE WALL OF CABINET FROM DOOR HINGING. APPROX. HALF WAY UP FROM BOTTOM OF CABINET, 2" IN FROM BACK OF CABINET (FOR STANDARD DEPTH CABINET, 3" IN FROM BACK OF CABINET FOR DEEPER DEPTH CABINET).

DOUBLE DOOR CABINETS (UP TO AND INCLUDING 36" WIDTH): 7/8" HOLE (WITH GROMMET) LOCATED ON EITHER LEFT OR RIGHT SIDE WALL OF CABINET, DEPENDING ON SPECIFICATION. 6" UP FROM BOTTOM OF CABINET (JUST ABOVE BOTTOM HINGE), 2" IN FROM BACK OF CABINET (FOR STANDARD DEPTH CABINET, 3" IN FROM BACK OF CABINET FOR DEEPER DEPTH CABINET).

DOUBLE DOOR CABINETS (INCLUDING AND ABOVE 39" WIDTH): 7/8" HOLE (WITH GROMMET) LOCATED BEHIND EITHER LEFT OR RIGHT MOST DOOR, ON EITHER SIDE OF INTERIOR CABINET DIVIDER, OPPOSITE DOOR(S), DEPENDING ON SPECIFICATION. WIRING DONE THROUGH TOP OF CABINET, FED THROUGH HOLLOW CABINET DIVIDER AND DOWN INTO RECEPTACLE CAN. DIVIDER PLACEMENT DEPENDING ON WIDTH OF ORDERED CABINET.

TRIPLE DOOR CABINETS (UP TO AND INCLUDING 36" WIDTH): 7/8" HOLE (WITH GROMMET) LOCATED ON EITHER LEFT OR RIGHT SIDE WALL OF CABINET, DEPENDING ON SPECIFICATION. 6" UP FROM BOTTOM OF CABINET (JUST ABOVE BOTTOM HINGE), 2" IN FROM BACK OF CABINET (FOR STANDARD DEPTH CABINET, 3" IN FROM BACK OF CABINET FOR DEEPER DEPTH CABINET).

TRIPLE DOOR CABINETS (INCLUDING AND ABOVE 39" WIDTH): 7/8" HOLE (WITH GROMMET) LOCATED BEHIND EITHER LEFT, MIDDLE OR RIGHT MOST DOOR, ON EITHER SIDE OF INTERIOR CABINET DIVIDER, OPPOSITE DOOR(S), OR IN EITHER LEFT MOST OR RIGHT MOST CORNER OF MEDICINE CABINET, DEPENDING ON SPECIFICATION. **[FOR LEFT/RIGHT MOST CORNER]: 7/8" HOLE (WITH GROMMET)** LOCATED ON OPPOSITE SIDE WALL OF CABINET FROM DOOR HINGING. 3" UP FROM BOTTOM OF CABINET, 2" IN FROM BACK OF CABINET (FOR STANDARD DEPTH CABINET, 3" IN FROM BACK OF CABINET FOR DEEPER DEPTH CABINET). **[FOR PLACEMENT ON SIDE OF INTERIOR CABINET DIVIDER]:** WIRING DONE THROUGH TOP OF CABINET, FED THROUGH HOLLOW CABINET DIVIDER AND DOWN INTO RECEPTACLE CAN. DIVIDER PLACEMENT DEPENDING ON WIDTH OF ORDERED CABINET.



OBUSBA-2 / OBUSBC-2 WIRING LOCATION:

SINGLE DOOR CABINETS (UP TO AND INCLUDING 40" HEIGHT): 7/8" HOLE (WITH GROMMET)
LOCATED ON TOP OF CABINET APPROX. HALF WAY ACROSS, (DEPENDING ON WIDTH OF
ORDERED CABINET) 2" IN FROM BACK OF CABINET (FOR STANDARD DEPTH CABINET, 3" IN
FROM BACK OF CABINET FOR DEEPER DEPTH CABINET)

SINGLE DOOR CABINETS (72" HEIGHT ONLY): 7/8" HOLE (WITH GROMMET) LOCATED ON
OPPOSITE SIDE WALL OF CABINET FROM DOOR HINGING. APPROX. HALF WAY UP FROM
BOTTOM OF CABINET, 2" IN FROM BACK OF CABINET (FOR STANDARD DEPTH CABINET, 3" IN
FROM BACK OF CABINET FOR DEEPER DEPTH CABINET).

DOUBLE DOOR CABINETS (UP TO AND INCLUDING 36" WIDTH): 7/8" HOLE (WITH GROMMET)
LOCATED ON TOP OF CABINET BEHIND LEFT OR RIGHT MOST DOOR. LOCATION DEPENDENT
ON DOOR SIZES OF UNIT AND SPECIFIED PLACEMENT, 2" IN FROM BACK OF CABINET (FOR
STANDARD DEPTH CABINET, 3" IN FROM BACK OF CABINET FOR DEEPER DEPTH CABINET).

DOUBLE DOOR CABINETS (INCLUDING AND ABOVE 39" WIDTH): 7/8" HOLE (WITH GROMMET)
LOCATED ON TOP OF CABINET BEHIND LEFT OR RIGHT MOST DOOR. LOCATION DEPENDENT
ON DOOR SIZES OF UNIT AND SPECIFIED PLACEMENT, 2" IN FROM BACK OF CABINET (FOR
STANDARD DEPTH CABINET, 3" IN FROM BACK OF CABINET FOR DEEPER DEPTH CABINET).

TRIPLE DOOR CABINETS (INCLUDING AND ABOVE 39" WIDTH): 7/8" HOLE (WITH GROMMET)
LOCATED ON TOP OF CABINET BEHIND LEFT, MIDDLE OR RIGHT MOST DOOR. LOCATION
DEPENDENT ON DOOR SIZES OF UNIT AND SPECIFIED PLACEMENT, 2" IN FROM BACK OF
CABINET (FOR STANDARD DEPTH CABINET, 3" IN FROM BACK OF CABINET FOR DEEPER DEPTH
CABINET).

For additional questions/inquiries, please contact our customer support hotline at 718-366-1966 or via email at sofiacabinets@gmail.com. Live chat is available 24/7 on our website; sofiamedicinecabinets.com.

