

Sensi-Touch Double Key Switch Guide (DOD-100)

Power & Dimming Button

- Tap once to turn LED lighting ON.
- Tap again to turn lighting OFF.
- Press and hold to dim or brighten the LED lights.
- Release at your desired brightness level.
- System remembers the last brightness setting.

Defogger Button

- Tap once to activate the defogger.
- Defogger automatically shuts off after 1 hour.
- Tap again to manually turn it off at any time.



Tips for Best Use

- Activate defogger a few minutes before showering.
- Avoid touching switches with wet hands.
- Ensure all electrical connections are installed by a licensed professional.

